



## H1 Gear Gate Lockout Kit Instructions

**Configure gear layout and change the number of gears on your H1 shifter.  
(compatible with H1 shifters 2025 spec and above).**

### Kit includes:

- Single gate lockout piece (3D printed with screw and nut)
- Double gate lockout piece (3D printed)



### Instructions:

1. Remove the front cowl by undoing the M4 grub screw with a 2mm Allen key.
2. Decide which gear layout you would like to achieve. In this example, the shifter is converted into a 4 speed + reverse (4RDR) shifter.
3. First insert the single gate lockout piece as shown (make sure the small cutaway is against the body of the shifter for ease of removal later).

Tighten the screw with a 2.5mm Allen key until the piece is clamped in place (avoid overtightening, ¼ turn should suffice).

4. Insert the double gate lockout piece as shown.

Re-fit the front cowl, this will hold the double gate lockout piece in place.

